


WWW.ACCURATE.ORG PO BOX 1654 97075 8687 SW HALL BLVD #100 97008 BEAVERTON OR USA 503.641.0118 FAX 503.646.3903

ACCESSORY SWITCH, MOUSE / TRACKBALL MODEL 8063



<u>CONTENTS</u>	PAGE
1.) GENERAL	A
2.) APPLICATION	А
3.) FEATURES AND BENEFITS	А
4.) SPECIFICATIONS	А
5.) CIRCUIT DESCRIPTION	А
6.) MECHANICAL OUTLINE	А
7.) INSTALLATION	А
8.) MAINTENANCE	А
9.) WARRANTY	А
<u>FIGURES</u>	
Figure 1 CIRCUIT DESCRIPTION	В
Figure 2 MECHANICAL OUTLINE	В
Figure 3 APPLICATION DIAGRAM	А

1. **GENERAL**

1.01 This practice provides application, specification, circuits and mechanical description, maintenance, installation, and warranty information relating to Accurate Electronics' Accessory Switch, Mouse / Trackball, Model 8063.

2. APPLICATION

2.01 Allows the computer operator to easily switch between a mouse and a trackball unit.

FEATURES AND BENEFITS 3.

- quick and simple installation
 - high density
 - compact design

SPECIFICATIONS 4.

4.01 Electrical

Mouse:		PS/2 or compatible
Trackball		PS / 2 or compatible
Mouse Conne	ector:	mini-din-6-pin receptacle
Trackball Co	nnector	mini-din-6-pin receptacle
Workstation (Connector:	mini-din-6-pin receptacle
Supplied:	six (6) ft. ca	ble with one (1) mini-din-6-pin

plug (male) at each end (for use between workstation and switch unit)

4.02 Environmental

Operating Temperature: 0 - 55° C Humidity up to 95% R.H.no condensation

4.03 Physical

Dimensions	2.400" L x 1.850" W x 0.925" H
	6.096cm L x 4.699cm W x 2.350cm H
Weight	1.5 oz. / 42.53g.
Finish	ABS - creme / white lettering

5. **CIRCUIT DESCRIPTION**

5.01 See FIGURE 1.

6. **MECHANICAL OUTLINE**

6.01 See FIGURE 2

7. **INSTALLATION**

7.01 Plug cable from mouse into connector marked "MOUSE".

7.02 Plug cable from trackball into connector marked "TRACKBALL"

7.03 Plug cable from the workstation into connector marked "WORKSTĂTION"

7.04 Use the switch to select either the trackball or the mouse.


8. **MAINTENANCE**

8.01 No preventive maintenance is required. General care is recommended.

9. WARRANTY

9.01 See WARRANTY in front of catalog.

FIGURE 3. APPLICATION DIAGRAM



ACCURATE ELECTRONICS INC.			
PO BOX 1654 97075 8687 SW HALL BLVD #100 97008	BEAVERTON OREGON USA 503-641-0118 FAX 503-646-3903	MODEL	8063
ACCESSORY SWITCH, MOUSE / TRACKBALL	MODEL 8063 WWW.ACCURATE.ORG	JAN	2015

This document contains proprietary information and is supplied for identification, maintenance, engineering evaluation or inspection purposes only and shall not be duplicated or disclosed without written permission of: ACCURATE ELECTRONICS INC By accepting this document the recipient agrees to make every effort to prevent unauthorized use of this information.

FIGURE 1. CIRCUIT DESCRIPTION

FIGURE 2. MECHANICAL OUTLINE

